

pure acoustics®

EDGEWATER

Wireless Stereo Speaker



User manual
&
Safety Guide

Thank you for choosing Pure Acoustics. We hope you enjoy each and every use of this product. We suggest that you read this user manual carefully before primary use in order to utilize all of the features in functions installed. Please store it in a safe place for future reference and pass it on to the next owner.

Caution & Safety Guide:

Please power off the unit when not in use. If the unit will not be in use for extended periods it is suggested that you disconnect the unit from its power source.

To prevent damage to the unit do not install in areas of extreme heat or in areas with direct exposure to sunlight.

Don't install the unit in or near a place where it may come in contact with rain, moisture or other liquids.

Install the unit on a horizontal, flat and firm surface with good ventilation. Never block the speaker, blocking these vents may cause damage to the speaker as a result of overheating.

To clean the unit, simply wipe it down using a dry, soft cloth. The unit should never be cleaned chemicals or detergent.

In the rear occurrence of malfunction do not attempt to repair the unit on your own. Contact a certified service professional for a proper diagnosis and repair.

Caution: Dismantling the unit on your own is dangerous and may cause damage to your person or property and will void the warranty.



The lightning flash is intended to alert the user to the presence of dangerous voltage within the product's enclosure and touching the internal components may result in electric shock to your person.



The exclamatory mark is intended to alert the user to the presence of important operating instructions.



To reduce the risk of electric shock or fire, do not remove the cabinet cover, please contact a service professional.

EDGEWATER

The founders of Pure Acoustics set out on a journey to create a speaker that would reach every listener. The result of their efforts and dedication to achieve perfection is the unmatched Edgewater speaker. The Edgewater is a world-class speaker like no other in its size or class; it will touch your heart and elevate your soul through every note.

Features:

Premium high fidelity sound distribution

Powerful 100W stereo sound distribution throughout any room or garden

Wireless Audio Stream music wirelessly from any smartphone or music player

Wired MIC Port 6.3mm microphone jack with independent volume control

3.5mm Brass Coil Cord included 3 meter cable offers wired connectivity for smartphones and other music devices

AM/FM Radio - Digital tuner offers non-stop music play with six one-touch stored preset stations

Tone Control - Independent master volume, bass and treble knobs for a more customized sound performance

High Capacity Lithium Battery Delivers hours of consistent, powerful and wireless music play outlet free

USB Charge Port - Keeps your smartphone and other USB equipped music source sufficiently charged

Battery Level Indicator 3 LED indicator lights display the battery's power level as low power, half power and full power

Luxurious genuine leather binding delivers a rich and elegant look that will enhance any room

Design - Faux leather binding delivers a rich and elegant look to enhance any room or setting

In The Box:

EDGEWATER wireless stereo speaker

AC Power Cable

User manual and safety guide

3 meter brass coiled auxiliary cable

Protective felt bag

Technical Specifications:

Bluetooth Version: 4.0

Power Output: 100W

Frequency Response: 55Hz-20kHz +/-3dB


Sensitivity: 88dB +/-3dB

Impedance: 4Ω

Rechargeable Battery : 7.4V 4400mAh

Drivers: 4" woofer (x2), 1" tweeter (x2)

Main Panel:



1. Power Switch powers the unit on/off
2. Mode allows you to select between the different inputs Bluetooth, AUX and FM Radio.
3. Mode indicator light illuminates blue in Bluetooth mode, illuminates green in AUX mode
4. Digital display indicates the current AM/FM station
5. One touch preset buttons allows you to quickly select one of 6 preset FM stations
6. Analog search buttons allow you to manually adjust the radio station
7. AM/FM switch. Allows you to move switch between AM/FM frequencies with ease
8. USB Charge port keeps connected devices sufficiently charged while on the go
9. 3.5mm Auxiliary input port for hard wire music play using music devices
10. 6.3mm wired microphone jack
11. LED charging indicator light
12. 3 LED battery indicator lights signal the current power level of the rechargeable battery
13. Bluetooth disconnect button allows you to quickly place the speaker back in pairing mode for a new connection
14. Master volume, Treble and Bass control knobs allow you to adjust the sound to your own desired levels
15. Independent wired microphone volume knob allows you to adjust the volume level of a connected microphone

Starting Out

Using the included AC power cable connect your speaker to an outlet to power it on and/or to charge the battery. Whenever the AC power cable is connected the charge LED indicator light (#11 in the diagram) will illuminate indicating your speaker is being charged.

On primary use the speaker should be charged for 3-5 hours or until the battery indicator light (#12 in the diagram) illuminates green.

Once the battery is fully charged the external adapter may be disconnected and stored for safe keeping and future use.

To power on the speaker flip the power switch to the "ON" position on the main panel (#1 in the diagram).

Selecting a Music Source

Push the "Mode" button (#2 in the diagram) to select between sources Bluetooth, AUX and AM/FM Radio. In Bluetooth the source indicator light (#3 in the diagram) will illuminate a solid blue, in AUX mode the indicator light will illuminate red and in AM/FM mode the indicator light will go out and the digital display will indicate the current station. Use the AM/FM switch (#7 in the diagram) to select between AM and FM frequencies.

Setting up a Bluetooth Connection

Push the mode button on the front panel until the source indicator light illuminates blue indicating the speaker is in pairing mode and ready to connect. Use the native controls on your Bluetooth device and power on Bluetooth then select scan to discover nearby devices. Select EDGEWATER from the list of discovered devices in order to pair and connect. Music played on your Bluetooth devices will now be heard through the EDGEWATER. To pair a secondary device push the disconnect button (#13 in the diagram) to quickly enter pairing mode again.

Auxiliary Connection

Push the mode button on the front panel until the source indicator light illuminates green indicating the speaker is in AUX mode.

Using the included auxiliary cable connect one end into the AUX port (#9 in the diagram) and insert the other end of the cable into the headphone jack on your music player. Music played on your music player will now be heard through the EDGEWATER.

Digital Tuner (AM/FM RADIO)

Push the mode button on the front panel until the source indicator light goes off and the digital screen illuminated indicating the speaker is in AM/FM mode.

Use the AM/FM switch to select between AM and FM frequencies.

Use the "Tune" arrows to scan through the different AM/FM stations.

Use the "Preset" digits 1-6 (#5 in the diagram) to select a preset station.

Press and hold the digit 1-6 to store a specific station as a preset station.

In AM/FM mode the digital screen will indicate the current station.

USB 5V/1A Charge Port

To charge your Smartphone, tablet or music player simply connect your USB data cable to the device you would like to charge and then to the USB charge port on the speaker (#8 in the diagram)

Connecting a Wired Microphone

To use a wired microphone, simply connect the 6.3mm jack into the MIC port on the speaker (#10 in the diagram).

Use the knob marked MIC (#15 in the diagram) to control the connected wired microphones' volume level.

Customizing the Sound

Use the Volume, Treble and Bass knobs to customize the sound levels of the speaker (#14 in the diagram).

ONCE AGAIN WE THANK YOU FOR PURCHASING THE EDGEWATER WIRELESS STEREO SPEAKER. IT IS OUR HOPE THAT YOU ENJOY THIS PRODUCT EVERY TIME IT IS PUT TO USE. THEREFORE, WE SUGGEST THAT YOU KEEP THIS USER MANUAL SAFE FOR FUTURE REFERENCE AND SO IT MAY BE PASSED ON TO THE NEXT OWNER.

PLEASE FEEL FREE TO VISIT OUR WEBSITE WWW.PURE-ACOUSTICS.COM FOR MORE INFORMATION ABOUT THIS PRODUCT AS WELL AS MANY MORE.

ENJOY!

pure acoustics®